

# 4C81 MANUAL

Version 2.1



# Table of Contents

GENERAL .....	1
DESCRIPTION .....	1
HARDWARE CONFIGURATION .....	2
GENERAL .....	2
BOOT OPTION .....	2
FPGA/CPLD LVTTTL CONNECTOR POWER .....	2
FPGA/CPLD LVTTTL OUTPUT VCC .....	2
NAND FLASH WRITE PROTECT .....	2
CONNECTORS .....	3
CONNECTOR AND DEFAULT JUMPER LOCATIONS .....	3
POWER/SERIAL CONSOLE CONNECTOR .....	4
4C81 SERIAL ADAPTER .....	4
FPGA/CPLD LVTTTL CONNECTOR .....	5
FPGA/CPLD LVDS CONNECTOR .....	6
ETHERNET CONNECTORS .....	6
JTAG CONNECTOR .....	7
CPU OPERATION .....	8
POWER .....	8
SERIAL CONSOLE .....	8
PC/104-PCI EXPANSION .....	8
MINI PCI EXPANSION .....	8
ETHERNET PORTS .....	8
GPIO BITS .....	9
FPGA OPTION .....	10
FPGA/CPU CONNECTIONS .....	10
FPGA CONFIGURATION .....	11
EXAMPLE FPGA CONFIG FILE .....	12
P4 PINOUT WITH EXAMPLE FPGA CONFIGURATION .....	12
P3 PINOUT WITH EXAMPLE FPGA CONFIGURATION .....	13
FPGAPOKE UTILITY .....	13
CPLD I/O .....	14
CPLD CPU INTERFACE .....	14
STANDARD CPLD CONFIGURATION .....	15
P4 PINOUT WITH STANDARD CPLD CONFIGURATION .....	15
P3 PINOUT WITH STANDARD CPLD CONFIGURATION .....	16
CPLD JTAG PINOUT .....	16

# Table of Contents

## SOFTWARE

GENERAL .....	17
BOOTLOADER .....	17
NET BOOT REQUIREMENTS .....	18

## NETBSD SOFTWARE

GENERAL .....	19
REMOTE FILE ACCESS .....	19
BOOT ROM UPDATING .....	19
NAND FLASH UPDATING .....	20
NETBSD NAND FLASH IMAGE .....	21
CHANGING NAND FLASH FILESYSTEM MODE .....	21
CHANGING PASSWORDS .....	21
ENABLING SSHD .....	22
CHANGING PASSWORDS .....	22
NETBSD NET BOOT BINARY DISTRIBUTION .....	22
NETBSD TOOLCHAIN .....	23

LINUX SOFTWARE .....	24
GENERAL .....	24
KERNEL BOOT OPTIONS .....	24
SEEPROM .....	24
KCMD/NETKCMD .....	24

SPECIFICATIONS .....	26
----------------------	----

# GENERAL

## DESCRIPTION

The 4C81 is a low cost, low power ARM based PC104-PCI CPU. Designed for networked applications, the 4C81 has two 10/100 baseT Ethernet interfaces and a slot for a WI-FI card or other Mini-PCI device. The 166 MHz CPU card consumes less than 2 watts total from a single 5V supply, making Solar powered applications practical.

System resources include 32M or 64M of RAM and 32M or more of NAND Flash memory, 36 I/O bits provided by either a CPLD or an FPGA and an RS-232 serial port. PC/104-PCI expansion is provided for up to 2 external bus master cards. The Ethernet interfaces generates hardware TCP checksums allowing close to wire speed routing through the 4C81.

An optional on card 200K or 400K gate Spartan3 FPGA with 32 bit local bus connection provides flexible user I/O or a custom processing accelerator. The FPGA has 36 User I/O pins available, 24 single ended LVTTTL I/O bits on a standard 50 pin header with interleaved grounds, and 12 I/O bits on a 20 pin 2MM header organized as 6 LVDS pairs with grounds between pairs.

The 4C81 can run Linux or NetBSD and has a jumper selectable netboot option with NFS support to allow simple system debug and software development.

# HARDWARE CONFIGURATION

## GENERAL

Jumper positions are specified with an upright card orientation. The 4C81 is upright when the top of the card (connector side) faces you, the PC/104-PLUS connector is away from you and the Ethernet connectors are on the right hand side.

## NETBOOT OPTION

The 4C81 can boot from its on card NAND flash or can netboot from a remote NFS server. This is useful in case the NAND flash becomes corrupted and for initial setup. W8 determines whether the 4C81 boots from the on card NAND flash chip or attempts a network boot. When W8 is in the right hand position, the 4C81 will boot from NAND flash. When W8 is in the left hand position the 4C81 will attempt a net boot. Network boot is always from Ethernet port 0.

## FPGA LVTTTL VCC

The I/O voltage for the FPGA pins that connect to the LVTTTL connector can be user selected. Jumper W7 selects the I/O voltage. When W7 is in the right hand position, the I/O voltage is 2.5V. When W7 is in the left hand position, the I/O voltage is 3.3V.

## FPGA LVTTTL CONNECTOR POWER


The LVTTTL connector can supply power to connected daughter cards. This power can be either 3.3V or 5V. When jumper W9 is in the left hand position, 5V is supplied on pin 49 of the LVTTTL I/O connector. When W9 is in the right hand position, 3.3V is supplied on pin 49.

## NAND FLASH WRITE PROTECT

The on card NAND flash can be protected against writes by removing jumper W3. This will prevent any change of NAND flash contents.

# CONNECTORS

## CONNECTOR AND DEFAULT JUMPER LOCATIONS



# CONNECTORS

## SERIAL/POWER CONNECTOR

P1 is the serial console and power connector. Note that the first 6 pins match the standard DE9 pin male (DTE) serial port pinout used on PC serial ports.

<b>PIN</b>	<b>FUNCTION</b>	<b>DIRECTION</b>
1	CD	TO 4C81
2	DSR	TO 4C81
3	RXD	TO 4C81
4	RTS	FROM 4C81
5	TXD	FROM 4C81
6	CTS	TO 4C81
7	+5V	TO 4C81
8	GND	TO 4C81
9	GND	TO 4C81
10	+5V	TO 4C81

## 4C81 SERIAL ADAPTER

The 4C81 serial adapter converts the DTE pinout of the 4C81 to DCE for direct connection to PC type 9 pin serial ports, and also has a 4 pin .1" 5V power connector. The 5V connector on the serial adapter is pinned out as follows:

1	+5V
2	GND
3	GND
4	+5V



# CONNECTORS

## FPGA/CPLD LVTTTL CONNECTOR

P4 is the FPGA/CPLD LVTTTL connector. P4 is a 50 pin .1" header. P4 is compatible with Mesa's Anything-I/O daughter cards with the restriction that FPGA I/O signals are not 5V tolerant. The CPLD I/O is 5V tolerant.

### P4 CONNECTOR PINOUT

P4 PIN	FUNC	FPGA PIN	P4 PIN	FUNC	FPGA PIN
1	IO0	77	3	IO1	78
5	IO2	79	7	IO3	80
9	IO4	82	11	IO5	83
13	IO6	84	15	IO7	85
17	IO8	86	19	IO9	87
21	IO10	89	23	IO11	90
25	IO12	92	27	IO13	93
29	IO14	95	31	IO15	96
33	IO16	97	35	IO17	98
37	IO18	99	39	IO19	100
41	IO20	102	43	IO21	103
45	IO22	104	47	IO23	105
49	POWER				

All even pins are connected to ground.

The POWER pin can be connected to either 3.3V or 5V power depending on the position of W7.

# CONNECTORS

## FPGA/CPLD LVDS CONNECTOR

P3 is a 20 pin 2mm header that connects to 12 FPGA I/O pins intended for use as a LVDS signals. P3 pinout is as follows:

P3 PIN	FUNC	FPGA PIN	P3 PIN	FUNC	FPGA PIN
1	GND	XX	11	LVDS3+	127
2	LVDS0+	118	12	LVDS3-	128
3	LVDS0-	119	13	GND	XX
4	GND	XX	14	LVDS4+	129
5	LVDS1+	122	15	LVDS4-	130
6	LVDS1-	123	16	GND	XX
7	GND	XX	17	LVDS5+	131
8	LVDS2+	124	18	LVDS5-	132
9	LVDS2-	125	19	GND	XX
10	GND	XX	20	+3.3V	XX

Note that The DCI (internal termination) feature does not work properly on Rev.A cards so if the LVDS feature is used, External termination must be supplied. This is fixed on card rev. B and above. CPLD versions of the 4C81 provide 12 I/O bits on the LVDS pins.

## ETHERNET CONNECTORS

The 4C81 has 2 Ethernet ports. Port 0 and Port 1. Port 0 is the port closest to the PC/104-PLUS connector. Both ports are standard RJ45 jacks. Low profile unshielded jacks are used in order to meet the PC/104 component height specifications.

# CONNECTORS

## JTAG CONNECTOR

P2 is a 10 pin 2mm connector that gives access to the JTAG boundary scan chain on the 4C81s CPU and FPGA.. P2 connector pinout is as follows:

<b>PIN</b>	<b>FUNCTION</b>	<b>DIR</b>
1	TMS	TO 4C81
2	TDI	TO 4C81
3	TDO	FROM 4C81
4	TCK	TO 4C81
5	/RST	TO 4C81
6	GND	
7	2.5V	
8	/ROMCS	TO 4C81 (test mode only)
9	/ROMOE	TO 4C81 (test mode only)
10	/ROMWE	TO 4C81 (test mode only)

# CPU OPERATION

## POWER

Power is supplied to the 4C81 via the serial console/power connector or the PC/104-PLUS bus. The 4C81 requires 5V power only. If 5V is not required for the PC/104-PLUS bus or a Mini-PCI card, the 5V supply can vary from 4V to 5V, as no 5V power is used on the 4C81 itself. If +12V and or -12V power are required by a PC/104-PLUS card, these must be supplied via the PC/104-PLUS bus.

## SERIAL CONSOLE

The 4C81 has a single serial port that is used as console I/O by the boot ROM and Linux or NetBSD. The default communication parameters are: 38400 baud, 8 bits, no parity. Note that the serial console pinout is DTE so that a null modem is required to connect the 4C81s console to A PC terminal emulator. A Null modem adapter is available from Mesa (NullModemX). This adapter also has the 5V power tap to simplify powering the 4C81.

## PC/104-PCI EXPANSION

The 4C81 is a PC/104-PCI card and can accept PC/104-PCI expansion cards. The 4C81 has a 3.3V PCI bus and will only work properly with 3.3V or universal PC/104-PCI cards. **5V cards are not supported and may damage the 4C81.** Two bus master cards are supported: slots 1, and 2. Slot 0 is reserved for the Mini-PCI card. A non bus master card can be accommodated in slot 3.

The 4C81 on card regulator can supply up to 1.5A of 3.3V power to the PC/104-PCI bus.

## MINI-PCI EXPANSION

A single Mini-PCI type 3A socket is provided for wireless and other Mini-PCI cards. This socket is slot 0 of the PCI expansion bus.

## ETHERNET PORTS

Two 10/100 BaseT Ethernet ports are provided. These ports support full duplex for high performance and auto-MDX for wiring simplicity. Three surface mount LEDs are provided on each port to monitor link status.

# CPU OPERATION

## CPU GPIO BITS

The 4C81 CPU chip has 16 GPIO bits that are used for various on card functions. The bit definitions are as follows:

GPIO-0	INPUT	PCI INTERRUPT
GPIO-1	INPUT	WLAN RFON SENSE
GPIO-2	INPUT	FPGA/CPLD IRQ
GPIO-3	OUTPUT	KSE0 ACTIVITY
GPIO-4	OUTPUT	KSE1 ACTIVITY
GPIO-5	OUTPUT	SERIAL EEPROM CHIP SELECT
GPIO-6	OUTPUT	GREEN LED CR3
GPIO-7	OUTPUT	FPGA /PWREN
GPIO-8	OUTPUT	NOR FLASH A22 (4M PAGE BIT)
GPIO-9	INPUT	NAND FLASH RDY/BUSY
GPIO-10	OUTPUT	FPGA /PROGRAM
GPIO-11	INPUT	FPGA /DONE SENSE
GPIO-12	OUTPUT	NAND FLASH CE
GPIO-13	I/O	EEPROM CLK – W8 SENSE
GPIO-14	I/O	EEPROM DI – W10 SENSE
GPIO-15	I/O	EEPROM DO – W6,W11 SENSE

# CPU OPERATION

## FPGA OPTION

The 4C81 can be provided with an on card Spartan3 FPGA with 200K or 400K gates. This FPGA can be used for custom I/O or a co-processor. 36 uncommitted FPGA I/O bits are available for user applications. 24 of these I/O bits are designed for single ended 3.3V or 2.5V LVTTTL applications and 12 are designed for differential 2.5V LVDS applications.

## FPGA CPU INTERFACE

The FPGA connects to the 4C81 CPUs 32 bit data bus. 9 addresses are connected to the FPGA giving a address span of 512 32 bit words. In addition the FPGA connects to CPU /ECS0 and read and write strobes.

CPU SIG	FPGA PIN	DIR	CPU SIG	FPGA PIN	DIR
MD0	65	BIDIR	MD13	7	BIDIR
MD1	63	BIDIR	MD14	8	BIDIR
MD2	60	BIDIR	MD15	10	BIDIR
MD3	59	BIDIR	MD16	11	BIDIR
MD4	51	BIDIR	MD17	12	BIDIR
MD5	50	BIDIR	MD18	13	BIDIR
MD6	47	BIDIR	MD19	14	BIDIR
MD7	46	BIDIR	MD20	15	BIDIR
MD8	1	BIDIR	MD21	17	BIDIR
MD9	2	BIDIR	MD22	18	BIDIR
MD10	4	BIDIR	MD23	20	BIDIR
MD11	5	BIDIR	MD24	21	BIDIR
MD12	6	BIDIR	MD25	23	BIDIR

# CPU OPERATION

## FPGA CPU INTERFACE

CPU SIG	FPGA PIN	DIR	CPU SIG	FPGA PIN	DIR
MD26	24	BIDIR	MA6	36	TO FPGA
MD27	25	BIDIR	MA7	44	TO FPGA
MD28	26	BIDIR	MA8	56	TO FPGA
MD29	27	BIDIR	MA9	57	TO FPGA
MD30	28	BIDIR	MA10	68	TO FPGA
MD31	30	BIDIR	ECSN0	40	TO FPGA
MA2	31	TO FPGA	EROEN	53	TO FPGA
MA3	32	TO FPGA	ERWEN0	52	TO FPGA
MA4	33	TO FPGA	CLK	55	TO FPGA
MA5	35	TO FPGA	LED	58	FROM FPGA

Notes: FPGA clock is normally the same as the SDRAM clock = 125 MHz.

LED is green LED CR10 on the bottom right hand side of the 4C81 card

## FPGA CONFIGURATION

The FPGA is configured by writing the bit file to the memory region defined for ECSN0. The address is unimportant as long as it is word aligned and in the FPGAMEM region.

Two processor GPIO bits are used by the FPGA interface, GPIO10 and GPIO11. GPIO10 is programmed as an output bit and controls the /PROGRAM pin of the FPGA. GPIO10 must be set low and then high again to prepare the FPGA to receive the configuration file. GPIO11 is programmed as an input and read backs the FPGAs done bit. The DONE bit will read high when the FPGA has been successfully configured.

The included FPGAUTIL will configure the 4C81's FPGA from a bit or PROM format file:

FPGAUTIL fourc81io.bit

# CPU OPERATION

## EXAMPLE FPGA CONFIGURATION FILE

An example FPGA configuration file (fourc81io.bit) is provided that includes 4 timers and 36 bits of I/O. The I/O is divided into two ports, a 24 bit port connected to P4 and a 12 bit port connected to P3. Each I/O bit can be individually programmed as an input or output.

The timers are 32 bit down counters that can be read on-the-fly. The count rate is determined by a 32 bit DDS oscillator running at 125 MHz, allowing precise count rate settability. Each counter can generate an interrupt. The counters can operate in free running or one shot mode. In one shot mode, the counters can be programmed to drive an I/O pin.

VHDL source and .UCF files for the example are provided with the software distribution image for the 4C81. A detailed register map of the example configuration is provided in the file 4c81ioregisters.

### P4 PINOUT WITH EXAMPLE FPGA CONFIGURATION

P1	PORTA0/TIMER0 OUT	P3	PORTA1/TIMER 1 OUT
P5	PORTA2/TIMER 2 OUT	P7	PORTA3/TIMER 3 OUT
P9	PORTA4	P11	PORTA5
P13	PORTA6	P15	PORTA7
P17	PORTA8	P19	PORTA9
P21	PORTA10	P23	PORTA11
P25	PORTA12	P27	PORTA13
P29	PORTA14	P31	PORTA15
P33	PORTA16	P35	PORTA17
P37	PORTA18	P39	PORTA19
P41	PORTA20	P43	PORTA21
P45	PORTA22	P47	PORTA23
P49	5V OR 3.3V	ALL EVEN PINS GROUNDED	



# CPU OPERATION

## EXAMPLE FPGA CONFIGURATION

### P3 PINOUT WITH EXAMPLE FPGA CONFIGURATION:

P1	GND	P2	PORTB0
P3	PORTB1	P4	GND
P5	PORTB2	P6	PORTB3
P7	GND	P8	PORTB4
P9	PORTB5	P10	GND
P11	PORTB6	P12	PORTB7
P13	GND	P14	PORTB8
P15	PORTB9	P16	GND
P17	PORTB10	P18	PORTB11
P19	GND	P20	+3.3V

## FPGAPOKE UTILITY

The FPGAPOKE utility allows direct access to FPGA registers for debugging. FPGAPOKE must be run as root. For example, using the example FPGA configuration provided:

```
FPGAPOKE -R 0x00 -g
```

Would read the FPGA configuration ID register (0x4c810001 for the example configuration)

```
FPGAPOKE -R 0x24 0x00ffffff -s
```

Would set 24 bit IO PORTA's DDR register so that all I/O pins were programmed as outputs.

```
FPGAPOKE -R 0x20 0x00aaaaaaaa -s
```

Would set the 24 output bits to alternate 1's and 0's

# CPU OPERATION

## CPLD I/O

The 4C81-N (without FPGA option) has a simple CPLD to provide 36 GPIO bits or other custom IO pins on connectors P3 and P4.

## CPLD CPU INTERFACE

The CPLD connects the low 16 bit half of the 4C81's 32 bit data bus. 6 addresses are connected to the CPLD giving a address span of 64 16 bit words. In addition the CPLD connects to CPU /ECS0, 125 MHz bus clock and read and write strobes, reset and CPU GPIO2 which can be used as an interrupt.

CPU SIG	CPLD PIN	DIR	CPU SIG	CPLD PIN	DIR
MD0	41	BIDIR	MD1	40	BIDIR
MD2	39	BIDIR	MD3	37	BIDIR
MD4	30	BIDIR	MD5	32	BIDIR
MD6	33	BIDIR	MD7	35	BIDIR
MD8	1	BIDIR	MD9	3	BIDIR
MD10	4	BIDIR	MD11	6	BIDIR
MD12	8	BIDIR	MD13	9	BIDIR
MD14	10	BIDIR	MD15	11	BIDIR
MA2	13	TO CPLD	MA3	14	TO CPLD
MA4	15	TO CPLD	MA5	16	TO CPLD
MA6	17	TO CPLD	MA7	18	TO CPLD
/CS0	28	TO CPLD	/OE0	29	TO CPLD
/WE0	27	TO CPLD	CLK	22	TO CPLD
/RST	12	TO CPLD			

# CPU OPERATION

## STANDARD CPLD CONFIGURATION

The 4C81-N (without FPGA option) has a simple CPLD (Xilinx 9572XL-PQ100) to provide 36 GPIO bits on connector P3 and P4. The standard CPLD configuration provides 36 I/O pins, 24 on P4, and 12 on P3. The 24 I/O bits on P4 can be individually programmed as inputs or outputs. The I/O on P3 is more limited. The lower 6 bits are input only while the top 6 bits can be programmed as all inputs or all output as a group.

### P4 PINOUT WITH STANDARD CPLD CONFIGURATION

P1	PORTA0	P3	PORTA1
P5	PORTA2	P7	PORTA3
P9	PORTA4	P11	PORTA5
P13	PORTA6	P15	PORTA7
P17	PORTA8	P19	PORTA9
P21	PORTA10	P23	PORTA11
P25	PORTB0	P27	PORTB1
P29	PORTB2	P31	PORTB3
P33	PORTB4	P35	PORTB5
P37	PORTB6	P39	PORTB7
P41	PORTB8	P43	PORTB9
P45	PORTB10	P47	PORTB11
P49	5V OR 3.3V	ALL EVEN PINS GROUNDED	

# CPU OPERATION

## P3 PINOUT WITH STANDARD CPLD CONFIGURATION:

P1	GND	P2	PORTC0
P3	PORTC1	P4	GND
P5	PORTC2	P6	PORTC3
P7	GND	P8	PORTC4
P9	PORTC5	P10	GND
P11	PORTC6	P12	PORTC7
P13	GND	P14	PORTC8
P15	PORTC9	P16	GND
P17	PORTC10	P18	PORTC11
P19	GND	P20	+3.3V

Note CPLD I/O pins use 3.3V levels ( $V_{OH} \approx 3.3V$ ) and are 5V tolerant.

## CPLD JTAG CONNECTOR

The CPLD on the 4C81N can be re-programmed externally via JTAG connector P5. P5 is a 6 pin inline .1" header. P5 pinout is as follows:

PIN	SIGNAL	PIN	SIGNAL	PIN	SIGNAL
1	TMS	2	TDI	3	TDO
4	TCK	5	GND	6	3.3V

Note, to allow in circuit programming of the CPLD via the CPU, the CPLD's JTAG pins also connect to GPIO pins on the CPU. To avoid interference from the CPU while externally programming the CPLD, the CPU should be held reset. This is easily done by placing a 2mm jumper on pins 5 and 6 of CPU JTAG connector P2.

# SOFTWARE

## GENERAL

The 4C81 can run NetBSD or Linux. The on card 32M byte NAND flash chip can accommodate a small distribution of either operating system. The 4C81 can also be ordered with either operating system pre-loaded on the NAND flash.

## BOOTLOADER

The 4C81 bootloader ROM loads the NetBSD or Linux Kernel from either NAND flash or from a server (NetBoot option). The netboot option is useful during software development as it does not require re-writing the NAND flash when updating the kernel. The netboot option can also be used to initialize the NAND flash on a 4C81 with a blank or corrupted NAND flash image. Jumpers W8 and W10 determine the low level boot options:

<b>W8</b>	<b>W10</b>	<b>FUNCTION</b>
LEFT	LEFT	NET BOOT - IGNORE SERIAL EEPROM SETTINGS  This is for Factory setup (Uses default MAC addresses and console baud rate etc) Default MAC address is: 00:60:1b:81:00:01 for KSE0 and 00:60:1b:81:00:02 for KSE1
LEFT	RIGHT	NORMAL NET BOOT  Net boot with normal Ethernet MAC addresses
RIGHT	LEFT	DEBUG FLASH BOOT
RIGHT	RIGHT	NORMAL USER FLASH BOOT

# SOFTWARE

## NETBOOT REQUIREMENTS

In order for the 4C81 to boot from the network, a NFS and a DHCP server must present and properly configured. The DHCP server must be configured with boot options in dhcpd.conf for the hardware address or address range of the 4C81(s)

For example:

```
host 4c81 {  
  
    hardware ethernet 00:60:1B:00:4C:81;  
  
    fixed-address 192.168.1.10;  
  
    server-name "myserver.mydomain.com";  
  
    option root-path "/mybootdir/4c81";  
  
    option host-name "4c81"; }  

```

The netboot option uses NFS to fetch the kernel so the root path in the example above must be exported, for example the following line in the exports file:

```
/mybootdir -alldirs -network 192.168.1 -mask 255.255.255.0
```

Would make the kernel available to the 4c81 as long as the kernel was readable and located in /mybootdir/4c81/.

# NETBSD SOFTWARE

## GENERAL

The NetBSD distribution for the 4C81 is a complete Unix with support for Atheros Wireless cards, Ethernet, Local FPGA, and serial console.

## REMOTE FILE ACCESS

In order to update the BOOT ROM or NAND flash image, the 4C81 needs access to the new image files. For small files like the boot ROM, it is possible to FTP the new image to a location in RAM disk (in /var for example) and then program the new image from there. This will not work for NAND filesystem images since there is not enough free space in the RAM disk to store the image. In order to write new NAND filesystem images you must have either a NFS server or Windows file share (Samba) available. To mount the files system you issue a command like:

```
mount -t nfs yourserver:/yourpath /mnt1           For NFS
```

or

```
mount -t smbfs //yourserver/yourpath /mnt1       For Windows share/SMBFS
```

## BOOT ROM UPDATING

The 4C81 boot ROM is a NOR flash device. A utility (flashutil) is provided to update the NOR flash boot ROM. Flashutil is invoked like this

```
flashutil bootfilename -W
```

Only root can run flashutil. ***Be careful that you update the flash with a legitimate boot image, as a update with the wrong file will make an unbootable 4C81 that will need to be returned to MESA for repair.*** All 4C81 boot images have a file name like boot81.xxxk where xxx is the boot file image size.

# NETBSD SOFTWARE

## NAND FLASH UPDATING

The NAND flash on the 4C81 is used as a live read-only file system. It contains the operating system and utility programs. New NAND flash images can be written to the 4C81 with the nandstore utility. Nandstore should only be run when the 4C81 is net booted or running in single user mode. To write a new NAND flash image, nandstore is invoked like this:

```
/mesa/nandstore build=nandfilesystemimage
```

Only root can run nandstore.

To modify an existing NAND file system image, the image must first be mounted using the vnd driver:

```
vnconfig /dev/vnd0 nandsfilesystemimage
```

```
mount /dev/vnd0c /mnt
```

Then the desired modification are made to the file system on /mnt. Next the file system must flush any pending file writes with a sync command and then the file system can be unmounted:

```
sync
```

```
umount /mnt
```

Finally the updated file system image can be written to the NAND flash with nandstore:

```
nandstore build=nandfilesystemimage
```



# NETBSD SOFTWARE

## NETBSD NAND FLASH IMAGE

The 32MB NAND flash image uses approximately 22 MB of the flash chip, leaving ~10 MB free for user applications. The 64MB NAND flash image has approximately 40 MB free. The images include a useful subset of full Unix system utilities. The kernel and NAND flash support DHCP, IPV6, SSH, NFS, SMBFS, Bridging interfaces, SH and KSH. The NAND flash file system is *read-only* by default so any changes need to be made by temporarily changing to RW mode or using the method described above for NAND FLASH UPDATING.

## CHANGING NAND FLASH FILESYSTEM MODE

In order to permanently change any program, script or file on the 4C81 NetBSD NAND flash distribution, the filesystem must be temporarily be placed into R/W mode. There are 2 scripts in the /mesa directory of the distribution that change the mode of the filesystem to Read/Write and to Read/Only:

/mesa/nandfsrw	Changes NAND filesystem mode to Read/Write (R/W)
/mesa/nandfsro	Changes NAND filesystem mode to Read/Only (R/O)

These scripts should be run in single user mode.

*Caution: If the NAND filesystem is set to R/W mode when in multi-user mode, log files, resolve.conf and other dynamic files may be created on the NAND flash drive. These files will cause problems when the file system is set back into R/O mode.*

## CHANGING PASSWORDS

An example of using the nand\_rw and nand\_ro scripts is changing a password:

/mesa/nandfsrw	Change NAND filesystem to R/W mode
passwd	Change passwd
/mesa/nandfsro	Change NAND filesystem back to R/O mode

# NETBSD SOFTWARE

## ENABLING SSHD

This can be done conveniently by running `/mesa/activatesshd`. This shell script will:

1. Set NAND file system into read/write mode if not already set
2. Generate the various keys needed by sshd (this will take a while)
3. Installs the `sshd=YES` line in `rc.conf` (if not already there)
4. Restores original NAND file system read/write state

## DEFAULT PASSWORDS

The 32MB NAND FLASH image has Default Passwords for root and one remote user:

USER	PASSWORD	NOTE
root	Mesa4C81	Only local logins allowed
remote	KS8695P	Remote ssh logins allowed

*These passwords **must** be changed before the 4C81 is deployed in a real application.*

## NETBSD NET BOOT BINARY DISTRIBUTION

To net boot the 4C81, you must install the following file sets in the NFS exported directory:

4C81NetBSD.tgz    Base distribution including compiler plus NAND image and flash utilities.

# NETBSD SOFTWARE

## NETBSD BUILD ENVIRONMENTS

The NFS base distribution mentioned above can be used to compile applications directly on the 4C81. It's no speed demon but may be acceptable for small projects. NFS swap may need to be configured for larger projects. Its also possible to cross compile applications and kernels on NetBSD 386, Linux-X86 or Windows (Using Cygwin). Contact Mesa for the latest cross build tool chain information.

# LINUX SOFTWARE

## GENERAL

The 4C81 can be supplied with a version 2.6 Linux system. Linux operation is somewhat different from NetBSD because a different NAND file system is used. This file system is YAFFS. Since the boot loader does not yet support YAFFS, the Linux kernel is first loaded from NOR flash and then launched. The kernel then has access to the NAND file system.

## KERNEL BOOT OPTIONS

Since the Linux kernel is booted from NOR flash, which normally should not be re-written except for major upgrades, kernel boot parameters are stored in the on card serial EEPROM. These are the normal command line type boot parameters. These boot parameters are changed by running the SEEPROM utility.

## SEEPROM

The seeprom utility allows reading and writing the serial EEPROM on the 4C81. All data in the EEPROM is stored as strings so that the contents of the serial EEPROM can be changed with the seeprom utility and any standard text editor.

*SEEPROM always reads the entire EEPROM or writes the entire EEPROM, so to avoid deleting existing serial EEPROM options, the serial EEPROM should be dumped to a file, the file edited, and then written back to the serial EEPROM:*

```
seeprom dump=aneepromfile
```

```
vi aneepromfile (make your changes, additions)
```

```
seeprom store=aneepromfile
```

Note that since the Ethernet MAC addresses are stored in the serial EEPROM, be careful that you do not accidentally delete or change these addresses when editing the text file dump of the serial EEPROM.

# LINUX SOFTWARE

## NETKCMD/KCMD

These variables are used to pass the Linux kcmd line to the booting kernel. For example the line:

```
netkcmd=root=/dev/nfs ip=dhcp
```

in the serial EEPROM when NFS booting would set Linux's root file system location and IP address source, while the line:

```
kcmd=root=/dev/mtdblock2 ip=dhcp
```

in the serial EEPROM when booting from NOR would set Linux's root file system location and IP address source.

If the netkcmd variable is not present, the default "root=/dev/nfs ip=dhcp" kcmd string is passed to the NFS booting Linux kernel. If the kcmd variable is not present, the default "root=/dev/mtdblock0,ro" string is passed to the NOR booting kernel.

A left-positioned W10 jumper makes the bootloader to ignore SEEPROM contents and use the defaults for both kcmd and netkcmd.

# SPECIFICATIONS

	MIN	TYP	MAX
POWER SUPPLY	4.5V	5V	5.5V

## POWER CONSUMPTION:

ACTIVE 166MHz No FPGA	----	350 mA	450 mA
ACTIVE 166 MHz FPGA TIMER	----	450 mA	550 mA

## AVAILABLE BUS POWER:

3.3V POWER FOR PC104+MiniPCI	----	----	1.5 A
------------------------------	------	------	-------

(3.3V power supplied to PC/104-PLUS bus and MiniPCI card by 4C81s on card 3.3V regulator)

5V POWER for PC104+MiniPCI	----	----	1 A
----------------------------	------	------	-----

(5V power is feed-through, there is no 5V regulator on 4C81)

## ENVIRONMENT:

OPERATING TEMP.	0°C		+70°C
-----------------	-----	--	-------

OPERATING TEMP. (-I version)	-40°C		+85°C
------------------------------	-------	--	-------

OPERATING HUMIDITY	0		95%
--------------------	---	--	-----

(NON-CONDENSING)