

7I43/7I43H MANUAL

V3.0

This page intentionally not blank

Table of Contents

| | |
|--------------------------------------------------------|----|
| GENERAL | 1 |
| DESCRIPTION | 1 |
| HARDWARE CONFIGURATION | 2 |
| GENERAL | 2 |
| FPGA CONFIGURATION SOURCE | 2 |
| USB POWER | 2 |
| POWER ENABLE | 2 |
| CONNECTOR POWER | 3 |
| BUS SWITCH MODE | 3 |
| PRE-CONFIGURATION PULL-UPS | 3 |
| CONNECTORS | 4 |
| CONNECTOR LOCATIONS AND DEFAULT JUMPER POSITIONS | 4 |
| I/O CONNECTORS | 6 |
| JTAG CONNECTOR | 8 |
| POWER CONNECTOR | 8 |
| EPP INTERFACE CONNECTOR | 9 |
| OPERATION | 10 |
| FPGA | 10 |
| EPP CONFIGURATION | 10 |
| USB CONFIGURATION | 11 |
| EEPROM CONFIGURATION | 12 |
| EXTRA EEPROM SPACE | 12 |
| RECONFIGURATION | 13 |
| CONFIGURATION FILE STARTUP OPTIONS | 13 |
| SC7143P and SC7143W | 13 |
| CLOCK SIGNALS | 14 |
| EPP-FPGA INTERFACE | 14 |
| USB-FPGA INTERFACE | 15 |
| ADDITIONAL 7143H INTERFACE PINS | 16 |
| LEDS | 16 |
| BUS SWITCH MODE | 17 |
| I/O LEVELS | 17 |
| STARTUP I/O STATE | 18 |
| DRIVING 5V REFERRED LOADS | 18 |
| TERMINATION | 18 |

Table of Contents

| | |
|--------------------------------|----|
| SUPPLIED CONFIGURATIONS | 19 |
| EPPIOPR8 | 19 |
| USBIOPR8 | 20 |
| LBP | 21 |
| EXAMPLE COMMANDS | 22 |
| LOCAL LBP COMMANDS | 23 |
| LOCAL LBP READ COMMANDS | 23 |
| LOCAL LBP WRITE COMMANDS | 25 |
| RPC COMMANDS | 26 |
| EXAMPLE RPC COMMAND LIST | 27 |
| AVAILABLE DAUGHTER CARDS | 28 |
| REFERENCE INFORMATION | 29 |
| SPECIFICATIONS | 29 |

GENERAL

DESCRIPTION

The 7I43 is a USB/EPP version of the FPGA based Anything I/O card series. It provides 48 programmable I/O bits. The 7I43H variant is a high speed USB version.

Initial FPGA configurations can be downloaded to the 7I43 via the USB (7I43 and 7I43H) or EPP (7I43 only) port. The 7I43/7I43H also has a serial EEPROM for FPGA configuration storage when the 7I43/7I43H is used in stand-alone applications.

The 48 I/O bits are available on two 50 pin connectors, 24 bits per connector. The 50 pin connectors have I/O module rack compatible pin-outs. The connector pin-out uses interleaved grounds for lower crosstalk and controlled impedance.

/Done, /Init and power status LEDs are provided for debugging purposes as are 8 FPGA driven LEDs. Several I/O interface daughter cards are available for the 7I43/7I43H. These cards include a 4 axis 3A Hbridge, a 2 Axis 3A stepper motor driver, an analog servo amp. interface, an RS-422/485 interface, and a debug LED card. One daughter card can plug directly onto the 7I43/7I43H.

Many IO configuration files are provided with the 7I43/7I43H including simple remote I/O, 4 and 8 axis servo motion control, 4 and 8 axis microstepping stepper motor control, multiple channel PWM generator, quadrature counters and more. VHDL source is provided for all configurations.

FPGA system clock is 50MHZ Oscillator. The Spartan3 used can multiply or divide this frequency to suitable values for application use.

The 7I43 uses a 200K or 400K gate Xilinx SpartanIII FPGA, and the 7I43H uses a 400K SpartanIII FPGA. Free development tools for the SpartanIII are available (Xilinx WebPack) from Xilinx's web site.

HARDWARE CONFIGURATION

GENERAL

Hardware setup jumper positions assume that the 7143 or 7143H card is oriented in an upright position, that is, with the USB connector towards the person doing the configuration, and the power connector on top right. In the following, "7143" refers to both the 7143 and the 7143H.

FPGA CONFIGURATION SOURCE

The 7143's FPGA can be configured via the USB port, The EPP port, or the on card serial EEPROM. Jumpers W4 and W5 select the configuration source. The 7143H does not have the EPP configuration option.

| W4 | W5 | MODE |
|------|------|----------------------------|
| DOWN | DOWN | EPP (PARALLEL PORT) CONFIG |
| DOWN | UP | USB CONFIG |
| UP | DOWN | EEPROM CONFIG |

USB POWER

The 7143 can be powered by the USB host. The maximum power that can be supplied by a USB host is 450 mA. This will be sufficient for most but not all 7143 applications. For applications that require more than the 450 mA supplied by the host, the 7143 has provisions for external power. W6 connects host USB power to the 7143's power supplies. To use host power, W6 must be set to the "UP" position. If external 5V power is used, W6 **must** be set to the "DOWN" position.

WARNING: Connecting an external 5V supply to the 7143 while W6 is in the "UP" position and a USB cable connects the 7143 to a host computer is likely to damage the computer by feeding external power 'backwards' into the USB port!

POWER ENABLE

The 7143 can be set to power-up only after the USB interface is activated. This is the suggested operational mode when the 7143 is interfaced via USB. For applications where the 7143 must operate without the USB interface, This function must be disabled. W7 controls the power up enable mode. When W7 is in the "UP" position, the 7143 power supplies are always enabled. When W7 is in the "DOWN" position, the 7143 power supplies will only be enabled when the USB interface is active.

HARDWARE CONFIGURATION

CONNECTOR POWER

The power connection on both I/O connectors (Pin 49) can supply either 3.3V or 5V power. Supplied power should be limited to 400 mA total. W1 selects the power supplied to both P3 and P4 . When W1 is in the "UP" position, 5V power is supplied to the connector. When W1 is in the "DOWN" position, 3.3V power is supplied to P3 and P4. Note that most Mesa I/O adapter cards that connect to Anything I/O cards require 5V.

BUS SWITCH MODE

Jumper W2 determines bus switch mode for all user I/O pins. When jumper W2 is in the "UP" position, 5V tolerant mode is selected, when 'down', 3.3V mode is selected. ***Note that 3.3V mode is not 5V tolerant. The FPGA can be damaged by input voltages greater than 4V in 3.3V mode.***


PRE-CONFIGURATION PULL-UPS

The 7143 has no pull-up resistors on its user I/O pins. This means that before these pins are configured, they will not have a defined state. If this is not desired, internal pull-up resistors on all FPGA pins can be enabled via Jumper W3. When W3 is in the "DOWN" position, user I/O will float until the FPGA is configured. When W3 is in the "UP" position, all FPGA pins including user I/O pins will have a pull-up resistor to 3.3V so the pins will be in a "HIGH" state. It is suggested that the internal pull-ups be enabled unless this causes a problem with connected I/O devices. Note that once the FPGA is configured, each FPGA input pin can have programmable pull-up or pull-down resistors.

CONNECTORS

CONNECTOR LOCATIONS AND DEFAULT JUMPER POSITIONS


7143-U shown -P version has different defaults



CONNECTORS

7143H CONNECTOR LOCATIONS AND DEFAULT JUMPER POSITIONS

P1 EXT 5V POWER



P5 - JTAG INTERFACE J1 - USB INTERFACE

CONNECTORS

I/O CONNECTORS

P3 and P4 are the 7143s I/O connectors. These are 50 pin box headers that mate with standard 50 conductor female IDC connectors. For information on which I/O pin connects to which FPGA pin, please see the 7143IO.PIN file on the 7143 distribution disk. 7143 IO connector pinouts are as follows:

P4 CONNECTOR PINOUT

| PIN | FUNC | PIN | FUNC | PIN | FUNC | PIN | FUNC |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|
| 1 | IO0 | 2 | GND | 3 | IO1 | 4 | GND |
| 5 | IO2 | 6 | GND | 7 | IO3 | 8 | GND |
| 9 | IO4 | 10 | GND | 11 | IO5 | 12 | GND |
| 13 | IO6 | 14 | GND | 15 | IO7 | 16 | GND |
| 17 | IO8 | 18 | GND | 19 | IO9 | 20 | GND |
| 21 | IO10 | 22 | GND | 23 | IO11 | 24 | GND |
| 25 | IO12 | 26 | GND | 27 | IO13 | 28 | GND |
| 29 | IO14 | 30 | GND | 31 | IO15 | 32 | GND |
| 33 | IO16 | 34 | GND | 35 | IO17 | 36 | GND |
| 37 | IO18 | 38 | GND | 39 | IO19 | 40 | GND |
| 41 | IO20 | 42 | GND | 43 | IO21 | 44 | GND |
| 45 | IO22 | 46 | GND | 47 | IO23 | 48 | GND |
| 49 | POWER | 50 | GND | | | | |

CONNECTORS

7143 I/O CONNECTORS

P3 CONNECTOR PINOUT

| PIN | FUNC | PIN | FUNC | PIN | FUNC | PIN | FUNC |
|-----|-------|-----|------|-----|------|-----|------|
| 1 | IO24 | 2 | GND | 3 | IO25 | 4 | GND |
| 5 | IO26 | 6 | GND | 7 | IO27 | 8 | GND |
| 9 | IO28 | 10 | GND | 11 | IO29 | 12 | GND |
| 13 | IO30 | 14 | GND | 15 | IO31 | 16 | GND |
| 17 | IO32 | 18 | GND | 19 | IO33 | 20 | GND |
| 21 | IO34 | 22 | GND | 23 | IO35 | 24 | GND |
| 25 | IO36 | 26 | GND | 27 | IO37 | 28 | GND |
| 29 | IO38 | 30 | GND | 31 | IO39 | 32 | GND |
| 33 | IO40 | 34 | GND | 35 | IO41 | 36 | GND |
| 37 | IO42 | 38 | GND | 39 | IO43 | 40 | GND |
| 41 | IO44 | 42 | GND | 43 | IO45 | 44 | GND |
| 45 | IO46 | 46 | GND | 47 | IO47 | 48 | GND |
| 49 | POWER | 50 | GND | | | | |

CONNECTORS

7143 JTAG CONNECTOR

P5 is a JTAG programming connector. It is not normally used since the 7143 can be programmed via the USB or EPP interface, but can be useful when debugging or reprogramming the CPLD. 3.3V levels are used for JTAG signals. A single JTAG connector is used for both the CPLD and the FPGA, with the CPLD being first in the JTAG chain.

P6 CONNECTOR PINOUT

| PIN | FUNCTION | DIRECTION |
|-----|----------|-----------|
| 1 | TMS | IN |
| 2 | TDI | IN |
| 3 | TDO | OUT |
| 4 | TCK | IN |
| 5 | GND | |
| 6 | +3.3V | |

POWER CONNECTOR

The 7143 has an external 5V power connector, P1. This connector supplies power to the 7143 in EPP, standalone, and USB applications where USB host power is not sufficient to power the 7143. On 7143 card with revisions B or less, P1 is a four pin .1" male header. On 7143s with revision C or greater or 7143Hs', P1 is a 2 pin 3.5MM pluggable screw terminal block. P1 pin-out is as follows:

P1 PINOUT (REV B and <)

| PIN | FUNCTION |
|-----|----------|
| 1 | +5V |
| 2 | GND |
| 3 | GND |
| 4 | +5V |

P1 PINOUT (7143 Rev C and >, all 7143H)

| PIN | FUNCTION |
|-----|----------|
| 1 | +5V |
| 2 | GND |

CONNECTORS

EPP INTERFACE CONNECTOR

On the 7143 (but not the 7143H), P2 is the EPP printer port interface connector. P2 is a 26 pin header. P2 pin-out matches stands DB25 printer port pin-out, allowing a simple flat cable with a DB25M IDC connector on one end and a 26 pin female header on the other end to interface the hosts printer port to the 7143.

| P2 PIN | DB25 PIN | SIGNAL | P2 PIN | DB25 PIN | SIGNAL |
|---------------|-----------------|---------------|---------------|-----------------|---------------|
| 1 | 1 | /STROBE | 2 | 14 | /AUTOFD |
| 3 | 2 | PD0 | 4 | 15 | /FAULT |
| 5 | 3 | PD1 | 6 | 16 | /INIT |
| 7 | 4 | PD2 | 8 | 17 | /SELECTIN |
| 9 | 5 | PD3 | 10 | 18 | GND |
| 11 | 6 | PD4 | 12 | 19 | GND |
| 13 | 7 | PD5 | 14 | 20 | GND |
| 15 | 8 | PD6 | 16 | 21 | GND |
| 17 | 9 | PD7 | 18 | 22 | GND |
| 19 | 10 | /ACK | 20 | 23 | GND |
| 21 | 11 | BUSY | 22 | 24 | GND |
| 23 | 12 | PERROR | 24 | 25 | GND |
| 25 | 13 | SELECT | 26 | VCC | |

Note: All handshake signals are available at the CPLD but only /STROBE, /AUTOFD,/SELECTIN and BUSY are forwarded to the FPGA with the standard CPLD configuration.

OPERATION

FPGA

The 7I43/7I43H uses a Xilinx Spartan-III FPGA in a 144 pin QFP package, Either PN XC3S200-5PQ144C or XC3S400-5PQ144C depending on 7I43 model.

HOST INTERFACE

The 7I43 uses either a USB or EPP printer port interface to the host. The 7I43H is USB only. These interfaces can be used for programming the FPGA and accessing the FPGA once programmed.

EPP CONFIGURATION

When the 7I43 is jumpered so the configuration source is EPP, *and* the FPGA is not configured (DONE is low), the on card CPLD implements two EPP registers to allow configuring the FPGA via the EPP port.

The two EPP registers are the control register and the data register. The control register is at EPP address 1 and has a single output bit (at D0) that controls FPGA /PROGRAM, and a single input bit (at D0) that reads the FPGA's done status. The data register at EPP address 0, is used for the byte wide configuration data. Reads from the data register will return the FPGA size in D0, 1 = 400K and 0 = 200K.

EPP CONFIGURATION PROCEDURE

EPPWriteAddress(1) ; Select EPP address 0x01 = control register
EPPWriteData(0) ; Set /PROGRAM low
EPPWriteData(1) ; Set /PROGRAM High
(Wait 100 Usec) ; Wait 100 Usec for FPGA to initialize
EPPWriteAddress(0) ; Select EPP address 0x00 = data register
EPPReadData ; Verify FPGA size
EPPWriteData(FPGAByte0) ; Write first byte of FPGA config data
EPPWriteData(FPGAByte1) ; Write second byte of FPGA config data
(write remaining FPGA config bytes)

OPERATION

EPP CONFIGURATION

Once the FPGA is configured, the CPLD EPP registers and EPP handshake logic are disabled and it is the FPGA's responsibility to handle the EPP host interface. The CPLD is still used at this point to forward some of the EPP port handshaking lines through to the FPGA for 5V tolerance.

USB CONFIGURATION

When the 7143 is jumpered so the configuration source is USB, and the FPGA is not configured (DONE is low), the on card CPLD implements a simple data handshake so all data sent to the USB port is written to the FPGA's configuration port.

The CPLD also will echo characters to indicate the FPGA size and DONE status. If a character is sent to the 7143 and the character's LSB is '1' the DONE status will be returned in the echoed character's LSB. If a character with a '0' LSB is sent, a character will be echoed indicating the FPGA size. This echoed character will have a '0' LSB for 200K 7143s and a '1' LSB for 400K 7143s. Since it is not desirable to deal with echoed characters for every configuration byte sent to the 7143, status character echoing is disabled after receiving 4 consecutive characters with a '0' LSB..

Once the FPGA is configured the CPLD data handshake is disabled and it is the FPGA's responsibility to handle the interface to the USB chip.

USB CONFIGURATION PROCEDURE

- Flush receive buffer ; Optional
- Send "1" character ; Optional
- Check echoed character for LSB = 0 (done should be low) ; Optional
- Send "0" character ; Optional
- Check echoed character LSB to determine FPGA size ; Optional
- Send 4 more "0" characters ; Disable echo
- Send configuration byte 0
- Send configuration byte 1
- (Send remaining configuration bytes)

OPERATION

EEPROM CONFIGURATION

For stand-alone applications and when it is not desired to have to preconfigure the FPGA via the host interface at power up, the 7143 can be configured via its serial EEPROM. Of course the Serial EEPROM must first be programmed with the desired configuration file. The serial EEPROM used is a ST M25P20 SPI flash serial EEPROM.

All access the serial EEPROM is via the FPGA, so programming the serial EEPROM is a "bootstrap" process, where the first step is programming the FPGA with a configuration giving host (EPP or USB) access to the serial EEPROM through the FPGA. Both the EPP and USB GPIO demo configurations allow this EEPROM access via a simple SPI interface built into the configuration.

The SCM7143P program is an example program for writing the serial EEPROM via the EPP port (DOS only), SCM7143W is a similar example program for writing the serial EEPROM via the USB port (windows only) The SCM programs rely on EPPIOPR8 (for EPP programming or USBIOPR8 (for USB) configuration file being preloaded into the FPGA before writing the serial EEPROM, as the serial EEPROM can only be accessed through the FPGA. EPPIOPR8 and USBIOPR8 have a simple SPI interface to allow EEPROM access.

EXTRA EEPROM SPACE

The serial configuration EEPROM on the 7143 has a capacity of 256K bytes, but the configuration bit file for the 400K Spartan 3 chip is only ~208K bytes, leaving 48 K bytes free for FPGA accessible non volatile storage. The 200K gate Spartan 3 chip uses only ~128K bytes of the serial EEPROM leaving 128K bytes free. This storage can be used for non-volatile settings or program storage in stand-alone 7143 applications.

OPERATION

RECONFIGURATION

Once the 7143 is configured, the CPLD loader is disabled. In order to reconfigure the FPGA, the FPGA must be reset via /PROGRAM. This can be done by having the FPGA assert its /RECONFIG pin (drive it low). If you wish to have the ability to reconfigure the FPGA without cycling the power, the FPGA configuration must include some way of asserting /RECONFIG. /RECONFIG is FPGA pin 52 on the 7143 and pin 44 on the 7143H.

Note that pin 52 is also USB2CLK input on the 7143H. This means that you should not load a standard 7143/7143H to a configuration file to a 7143H and configure the USB chip for synchronous operation, not only will it not work, it will cause a bus conflict.

CONFIGURATION FILE STARTUP OPTIONS

Important: Because the 7143s CPLD stops configuration when DONE is asserted, the configuration file startup options must be set so that asserting DONE is the last configuration step. Suggested startup options are as follows:

| | |
|------------------------------|----------------|
| FPGA STARTUP CLOCK: | CCLK |
| DONE: | 6 |
| ENABLE OUTPUTS: | 5 |
| RELEASE WRITE ENABLE: | 4 |
| RELEASE DLL: | NO WAIT |

SC7143P and SC7143W

Two utility programs, SC7143P.EXE and SC7143W are provided to send configuration files to the 7143. SC7143P is a DOS only program and SC7143W is a windows only program.

SC7143P is invoked with the FPGA configuration file and the Hexadecimal EPP port base address on the command line:

```
SC7143P FPGAFILE.BIT 378
```

SC7143W is invoked with the FPGA configuration file and the COM port on the command line:

```
SC7143W FPGAFILE.BIT COM6
```

SC7143P and SC7143W use binary FPGA configuration files. These files can standard Xilinx BIT files or Xilinx PROM format files.

OPERATION

CLOCK SIGNALS

The 7143 has a 50 MHz crystal controlled clock signal routed to pin 53 (GCLK3) on the FPGA. Four user I/O pins are also GCLK pins:

| IO BIT | GCLK | FPGA PIN | IO BIT | GCLK | FPGA PIN |
|---------------|-------------|-----------------|---------------|-------------|-----------------|
| IOBIT0 | GCLK6 | 127 | IOBIT24 | GCLK7 | 128 |
| IOBIT17 | GCLK4 | 124 | IOBIT40 | GCLK5 | 125 |

EPP-FPGA INTERFACE

The interface from host EPP printer port to the FPGA uses 12 FPGA pins. These consist of an eight bit bidirectional data bus (D0..D7), and four handshake lines. Note that the handshake lines are fed through the CPLD so depend on the standard CPLD configuration. The D bus connects to the FPGA through 100 Ohm resistors. These resistors provide 5V tolerance and series line termination for driving the cable.

| P2 PIN | EPPNAME | SPPNAME | FPGA PIN | DIRECTION |
|---------------|----------------|----------------|-----------------|------------------|
| 1 | /WRITE | /STROBE | 84 | TO FPGA |
| 2 | /DSTROBE | /AUTOFD | 79 | TO FPGA |
| 8 | /ASTROBE | /SELECTIN | 80 | TO FPGA |
| 21 | WAIT | BUSY | 82 | FROM FPGA |
| 3 | D0 | D0 | 68 | BIDIR |
| 5 | D1 | D1 | 63 | BIDIR |
| 7 | D2 | D2 | 60 | BIDIR |
| 9 | D3 | D3 | 59 | BIDIR |
| 11 | D4 | D4 | 51 | BIDIR |
| 13 | D5 | D5 | 50 | BIDIR |
| 15 | D6 | D6 | 47 | BIDIR |
| 17 | D7 | D7 | 46 | BIDIR |

OPERATION

EPP-FPGA INTERFACE

The EPP interface implements a simple multiplexed 8 bit data/address bus. The EPPIOPR8 configuration can be used as an example of an EPP interface in the FPGA. This is a simple GPIO interface organized as six eight bit ports.

USB-FPGA INTERFACE

The USB interface differs between the 7I43 and 7I43H. The 7I43 uses a FTDI USB interface chip, the FT245R. This is a Full speed interface chip (12 Mbps max). The FT245R appears as a single endpoint communication device, basically a simple bidirectional byte-stream with receive and transmit FIFOs. In order to use the USB configuration and interface you must load the appropriate drivers for your operating system. These drivers are available at FTDICHIP.COM. The utilities supplied with the 7I43 utilize the VCP (Virtual COM Port) series drivers.

The 7I43H uses a FT2232H high speed USB interface chip (480 Mbps). Unlike the FT245R used in the 7I43, the FT2232H appears as two serial ports. Only the first port is used by the 7I43H. The supplied configurations support the same FIFO interface mode as the 7I43 and the same pinout, but the 7I43H also has the FPGA connections to support the high speed synchronous mode that allows host transfer rates up to 25M bytes per second. The default mode is limited to 10 M bytes per second.

The FPGA interface uses a bidirectional 8 bit data bus that is shared with the EPP interface on the 7I43). Because of this sharing you cannot operate the USB and EPP interfaces simultaneously.

| SIGNAL NAME | FPGA PIN | DIRECTION | FUNCTION |
|--------------------|-----------------|------------------|--------------------|
| USBWRITE | 56 | FROM FPGA | XMIT DATA STROBE |
| /USBRD | 55 | FROM FPGA | RECV DATA STROBE |
| /USBTXE | 83 | TO FPGA | XMIT FIFO NOT FULL |
| /USBRXF | 69 | TO FPGA | RECV FIFO HAS DATA |
| D0 | 68 | BIDIR | DATA BUS |
| D1 | 63 | BIDIR | DATA BUS |
| D2 | 60 | BIDIR | DATA BUS |
| D3 | 59 | BIDIR | DATA BUS |

OPERATION

| SIGNAL NAME | FPGA PIN | DIRECTION | FUNCTION |
|--------------------|-----------------|------------------|-----------------|
| D4 | 51 | BIDIR | DATA BUS |
| D5 | 50 | BIDIR | DATA BUS |
| D6 | 47 | BIDIR | DATA BUS |
| D7 | 46 | BIDIR | DATA BUS |

ADDITIONAL 7143H USB INTERFACE PINS

The 7143H can use the FT2232H's high speed synchronous FIFO interface mode and the SPI mode on channel B. These additional pins are connected as follows:

| SIGNAL NAME | FPGA PIN | DIRECTION | FUNCTION |
|--------------------|-----------------|------------------|-------------------------|
| USB2CLK | 52 | TO FPGA | SYNC FIFO CLOCK |
| /USB2OE | 82 | FROM FPGA | SYNC FIFO OUTPUT ENABLE |
| UDI | 57 | FROM FPGA | SPI DATA IN |
| UDO | 84 | TO FPGA | SPI DATA OUT |
| USK | 85 | TO FPGA | SPI CLOCK |
| /UCS | 79 | TO FPGA | SPI CHIP SELECT |

LEDS

The 7143 has 8 FPGA driven user LEDS. These green LEDS are located in the top center of the card. They can be used for any purpose, and can be helpful as a simple debugging feature. A low output signal from the FPGA lights the LED. See the 7143MISC.PIN file for FPGA pin locations of the LED signals.

In addition to the user LEDs there are three other LEDs that display board status information. These status LEDs are on the lower right hand side of the card just above the USB connector, The LEDs are a yellow PWR LED, a red /DONE LED and a red /INIT LED. The /DONE and /INIT LED can be used to determine FPGA configuration status. The /INIT LED will be illuminated when /PROGRAM is asserted or when a CRC error has occurred during the configuration process. The /DONE LED will be illuminated when the FPGA is not configured.

OPERATION

BUS SWITCH MODE

The 7143 uses bus switch devices in series with all I/O pins. These devices allow the 7143 inputs to be 5V tolerant and allow the I/O pins to be pulled up to 5V. The bus switch input protection function works by disconnecting the FPGA from the IO pins when the IO pin voltage rises above a preset threshold. This threshold determines the bus switch operational mode. We refer to the modes as 5V tolerant mode and 3.3V mode.

When in 5V tolerant mode, the inputs and tri-stated outputs may be pulled up to 5V. This allows driving 5V referred loads such as I/O module racks and connecting inputs to 5V logic. The disadvantage of 5V mode is that the output impedance is higher in the high output state (when the FPGA pins are at 3.3V) as the bus switch is off when the FPGA pin is at 3.3V.

When 3.3V mode is selected, the bus switch is always fully on unless input voltages >4V are applied, at which point the bus switch disconnects the FPGA from the I/O pin. 3.3V mode is suggested for general use. **Note that 3.3V mode is not 5V tolerant.** When the bus switch mode jumper W2 is in the 'up' position, 5V mode is selected, when 'down', 3.3V bus switch mode is selected.

IO LEVELS

The FPGA used on the 7143 is a Spartan3. The Spartan3 supports many I/O standards. The 7143 does not support use of the I/O standards that require input reference voltages, also VCCIO is fixed at 3.3V. The available I/O options for are LVTTTL, LVCMOS_33, LVDCI_33, and LVDCI_33_DV2 .

The Spartan3 FPGA chip used on the 7143 is not 5V tolerant but external bus switch parts are used on the 7143 to make the I/O pins 5V tolerant. The bus switch parts disconnect the FPGA pins from the I/O pins when the I/O pins are driven to positive voltage levels that would damage the FPGA.

The voltage level that causes disconnect can be selected to be ~4V (3.3V mode) or ~3.3V (5Vmode). For most applications, the 3.3V mode should be used. The 5V tolerant mode is useful when driving 5V referred loads or accepting 5V logic levels.

Note that there is no protection against negative input voltages other than the input clamp diodes in the FPGA and bus switches, so negative input voltages must be limited to -.5V

OPERATION

STARTUP I/O STATE

When the 7143 is used to control external equipment that is sensitive to the initial pin states, the pre-configuration pull-ups should be enabled (W3 UP), and for most configurations, pull-ups resistor should be configured on any I/O pin that is not driven when configuration is complete (bi-directional pins and pins whose function is assigned by software). Since the only definable pre-configuration state is with pull-up resistors on the I/O, this means the proper I/O polarity is active low (so that all outputs are in the in-active state at power up)

DRIVING +5V REFERRED LOADS

When driving external loads like Solid State Relays (SSRs) with an active low output, and the +SSR terminal connected to +5V, the 7143 output should be configured for 5V tolerance, and the output should be driven in open drain mode. This is because the 7143 outputs only swing to 3.3V in normal mode, leaving 1.7V ($5V - 3.3V$) driving the SSR when the output is high and the SSR should be off.

TERMINATION

The FPGA used on the 7143 supports series and parallel termination that can be programmed on a pin-for-pin basis. This feature is called DCI. The 7143 supports DCI on all user I/O pins. The DCI reference resistors are all 100 Ohm 1%.

SUPPLIED CONFIGURATIONS

EPPIOPR8

GENERAL

The EPPIOPR8 configuration is a simple six port GPIO configuration with EPP interface. The GPIO is organized as six eight bit ports, each with an associated Data Direction Register (DDR). The EPPIOPR8 configuration can be used as a starting point for more complicated user configurations. There are two EPPIOPR8 configuration files, EPPIO8-2.BIT for the 200K and EPPIO8-4.BIT for 400K versions of the 7143.

| PORT | DATA REG | DDR | IO BITS | CONNECTOR |
|------|----------|------|---------|-----------|
| 0 | 0x10 | 0x20 | 0..7 | P4 |
| 1 | 0x11 | 0x21 | 8..15 | P4 |
| 2 | 0x12 | 0x22 | 16..23 | P4 |
| 3 | 0x13 | 0x23 | 24..31 | P3 |
| 4 | 0x14 | 0x24 | 32..39 | P3 |
| 5 | 0x15 | 0x25 | 40..47 | P3 |

In addition to the GPIO bits, the EPPIOPR8 configuration has a simple SPI interface to the configuration EEPROM and a reconfiguration port.. The SPI port allows the utility program SCM7143P to write configuration data to the serial EEPROM. These registers are mapped as follows:

| REGISTER | ADDRESS | FUNCTION |
|----------|---------|---------------------------------------------------|
| SPICS | 0x7D | Single I/O bit to control SPI Chip Select (bit 0) |
| SPIDATA | 0x7E | Eight bit SPI shift register |
| RECONFIG | 0x7F | Reconfig - Writing 0x5A here resets FPGA |

The 7143 is delivered with the EPPIOPR8 configuration installed for factory and initial user checking.

SUPPLIED CONFIGURATIONS

USBIOPR8

GENERAL

The USBIOPR8 configuration is a simple six port GPIO configuration almost identical to the EPPIOPR configuration. It is different because the USB interface is a simple bidirectional byte-stream without separate address and data. Because of this a Little Binary Protocol (LBP) is used to communicate with standard addressable peripherals in the 7143 FPGA configuration. The GPIO is organized as six eight bit ports, each with an associated Data Direction Register (DDR). The USBIOPR8 configuration can be used as a starting point for more complicated user configurations. There are two USBIOPR8 configuration files, USBIO8-2.BIT for the 200K and USBIO8-4.BIT for 400K versions of the 7143.

| PORT | DATA REG | DDR | IO BITS | CONNECTOR |
|------|----------|-------|---------|-----------|
| 0 | 0x010 | 0x020 | 0..7 | P4 |
| 1 | 0x011 | 0x021 | 8..15 | P4 |
| 2 | 0x012 | 0x022 | 16..23 | P4 |
| 3 | 0x013 | 0x023 | 24..31 | P3 |
| 4 | 0x014 | 0x024 | 32..39 | P3 |
| 5 | 0x015 | 0x025 | 40..47 | P3 |

In addition to the GPIO bits, the USBIOPR8 configuration has a simple SPI interface to the configuration EEPROM, a LED port, and a reconfiguration port.. The SPI port allows the utility program SCM7143W to write configuration data to the serial EEPROM. These registers are mapped as follows:

| REGISTER | ADDRESS | FUNCTION |
|----------|---------|---------------------------------------------------|
| LED | 0x07A | 8 Status LEDs ('1' = on) |
| SPICS | 0x07D | Single I/O bit to control SPI Chip Select (bit 0) |
| SPIDATA | 0x07E | Eight bit SPI shift register |
| RECONFIG | 0x07F | Reconfig - Writing 0x5A here resets FPGA |

SUPPLIED CONFIGURATIONS

USBIOPR8

LBP

LBP is a simple master slave protocol where the host sends read, write, or RPC commands to the 7143, and the 7143 responds. LBP allows the host (master) to efficiently access registers on the slave (7143) via a simple bidirectional byte oriented protocol.

LBP commands always start with a command header byte. This header specifies whether the command is a read or a write, the number of address bytes(0, or 2), and the number of data bytes(1 through 8).The 0 address size option indicates that the current address pointer should be used. This address pointer will be post incremented by the data size if the auto increment bit is set.

RPC commands allow any of up to 64 stored commands to be executed in response to the single byte command.

LBP DATA READ/WRITE COMMAND

| | | | | | | | |
|---|---|----|-----|----|----|-----|-----|
| 0 | 1 | WR | RID | AI | AS | DS1 | DS0 |
|---|---|----|-----|----|----|-----|-----|

- Bit 7.. 6 **CommandType:** Must be 01b to specify data read/write command
- Bit 5 **Write:** 1 to specify write, 0 to specify read
- Bit 4 **RPCIncludesData:** 0 specifies that data is from stream, 1, that data is from RPC (RPC only, ignored for non RPC commands)
- Bit 3 **AutoInc:** 0 leaves address unchanged, 1 specifies that address is post incremented by data size in bytes.
- BIT 2 **AddressSize:** 0 to specify current address, 1 to specify 2 byte address.
- Bit 1..0 **DataSize:** Specifies data size, 00b = 1 bytes, 01b = 2 bytes, 10 b= 4 bytes, 011b = 8 bytes.

When multiple bytes are specified in a read or write command, the bytes are always written to or read from successive addresses. That is, a 4 byte read at location 0x21 will read locations 0x21, 0x22, 0x23, 0x24. The address pointer is not modified after the command unless the AutoInc bit is set.

SUPPLIED CONFIGURATIONS

USBIOPR8

EXAMPLE LBP COMMANDS

Write 4 bytes (0xAA, 0xBB, 0xCC, 0xDD) to addresses 0x010, 0x011, 0x012, 0x013 with AutoInc so that the address pointer will be left at 0x014 when the command is completed:

| COMMAND BITS | CT1 | CT0 | WR | RID | AI | AS | DS1 | DS0 |
|-------------------------------|-----|-----|----|-----|----|----|-----|-----|
| LBPWrite: 2 add 4 data | 0 | 1 | 1 | 0 | 1 | 1 | 1 | 0 |
| Write Address LSB | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| Write Address MSB | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Write data 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 |
| Write Data 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 | 1 |
| Write Data 2 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 |
| Write Data 3 | 1 | 1 | 0 | 1 | 1 | 1 | 0 | 1 |

Write 2 more bytes (0xEE, 0xFF) at 0x014 and 0x015:

| COMMAND BITS | CT1 | CT0 | WR | RID | AI | AS | DS1 | DS0 |
|-------------------------------|-----|-----|----|-----|----|----|-----|-----|
| LBPWrite: 0 add 2 data | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 1 |
| Write data 0 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 0 |
| Write data 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Read 8 bytes at 0x010, 0x011, 0x012, 0x013, 0x014, 0x015, 0x016, 0x017:

| COMMAND BITS | CT1 | CT0 | WR | RID | AI | AS | DS1 | DS0 |
|------------------------------|-----|-----|----|-----|----|----|-----|-----|
| LBPRead: 2 add 8 data | 0 | 1 | 0 | 0 | 0 | 1 | 1 | 1 |
| Read Address LSB | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| Read Address MSB | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

SUPPLIED CONFIGURATIONS

USBIOPR8

LOCAL LBP COMMANDS

In addition to the basic data access commands there are a set of commands that access LBP status and control the operation of LBP itself. These are organized as READ and WRITE commands

LOCAL LBP READ COMMANDS

(HEX), all of these commands return a single byte of data.

0xC0 Get unit address (dont-care for USB devices)

0xC1 Get LBP status

LBP Status bit definitions:

BIT 7 Reserved

BIT 6 Command Timeout Error

BIT 5 Invalid write Error (attempted write to protected area)

BIT 4 Buffer overflow error

BIT 3 Watchdog timeout error

BIT 2 Reserved

BIT 1 Reserved

BIT 0 CRC error

0xC2 Get CRC enable status

0xC3 Get CRC error count

0xC4 .. 0xC9 Reserved

0xCA Get Enable_RPCMEM access flag

0xCB Get Command timeout (in mS for USB and character times/10 for serial)

0xCC Get Non-volatile memory flag

0xCD Get External memory flag

0xCE.. 0xCF Reserved

SUPPLIED CONFIGURATIONS

USBIOPR8

LOCAL LBP READ COMMANDS

0xD0 .. 0xD3 4 character card name

0xD5 .. 0xD7 4 character configuration name (only on some configurations)

0xD8 Get low address

0xD9 Get high address

0xDA Get LBP version

0xDB Get LBP Unit ID (Serial only, not used with USB)

0xDC Get RPC Pitch

0xDD Get RPC SizeL (Low byte of RPCSize)

0xDE Get RPC SizeH (High byte of RPCSize)

0xDF Get LBP cookie (returns 0x5A)

SUPPLIED CONFIGURATIONS

USBIOPR8

LOCAL LBP WRITE COMMANDS

(HEX), all of these commands except 0xFF expect a single byte of data.

0xE0 Reserved

0xE1 Set LBP status (0 to clear errors)

0xE2 Set CRC check enable (Flag non-zero to enable CRC checking)

0xE3 Set CRC error count

0xE4 .. 0xE9 Reserved

0xEA Set Enable_RPCMEM access flag (non zero to enable access to RPC memory)

0xEB Set Command timeout (in mS for USB and character times for serial)

0xEC Set Non-volatile memory flag

0xED Set External memory flag (non zero for external memory mode)

0xEE .. 0xEF Reserved

0xF0 .. 0xF6 Reserved

0xF7 Write LEDs

0xF8 Set low address

0xF9 Set high address

0xFA Add byte to current address

0xFB .. 0xFC Reserved

0xFD Set unit ID (serial only)

0xFE Reset LBP processor if followed by 0x5A

0xFF Reset LBP parser (no data follows this command)

SUPPLIED CONFIGURATIONS

USBIOPR8

RPC COMMANDS

RPC commands allow previously stored sequences of read/write commands to be executed with a single byte command. Up to 64 RPC's may be stored. RPC write commands may include data if desired, or the data may come from the USB serial data stream. RPCs allow significant command compression which improves communication bandwidth.

LBP RPC COMMAND

| | | | | | | | |
|---|---|------|------|------|------|------|------|
| 1 | 0 | RPC5 | RPC4 | RPC3 | RPC2 | RPC1 | RPC0 |
|---|---|------|------|------|------|------|------|

Bit 7..6 **CommandType:** must be 10b to specify RPC

Bit 5..0 **RPCNumber:** Specifies RPC 0 through 63

In the USBIOPR8 configuration, RPCPitch is 0x10 bytes so each RPC command has native size of 0x10 bytes and start 0x10 byte boundaries in the RPC table area. RPCs can cross RPCPitch boundaries if larger than RPCPitch RPCs are needed. The stored RPC commands consist of LBP headers and addresses, and possibly data if the command header has the RID bit set. RPC command lists are terminated by a 0 byte.

The RPC table is accessed at addresses 0 through RPCSize-1 This means with a RPCPitch of 0x10 bytes, RPC0 starts at 0x0000, RPC1 starts at 0x0010, RPC2 starts at 0x0020 and so on.

Before RPC commands can be written to the RPC table, the RPCMEM access flag must be set. The RPCMEM access flag must be clear for normal operation.

SUPPLIED CONFIGURATIONS

USBIOPR8

EXAMPLE RPC COMMAND LIST

This is an example stored RPC command list. Note RPC command lists must start at a RPCPitch boundary in the RPC table but an individual RPC list can extend until the end of the table. This particular RPC example contains 3 LBP commands and uses 11 bytes starting at 0x0050 (RPC5 for 0x10 pitch RPC table)

Command1. Writes two data bytes to port 0x10, 0x11 with 2 data bytes supplied by host

Command2. Reads two data bytes from port 0x12,0x13

Command3. Writes a single byte (0xAA) to port 0x14, data contained in RPC table

| COMMAND BITS | CT1 | CT0 | WR | RID | I | AS | DS1 | DS0 |
|-------------------------------|-----|-----|----|-----|---|----|-----|-----|
| LBPWrite: 2 add 2 data | 0 | 1 | 1 | 0 | 0 | 1 | 0 | 1 |
| Write Address LSB | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| Write Address MSB | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| LBPRead: 2 add 2 data | 0 | 1 | 0 | 0 | 0 | 1 | 0 | 1 |
| Read Address LSB | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 |
| Read Address MSB | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| LBPWrite 2 add 1 data | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 0 |
| Write Address LSB | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 |
| Write Address MSB | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Write Data | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 |
| Terminator | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

The data stream for this RPC would consist of these 3 bytes:

| COMMAND BITS | CT1 | CT0 | R5 | R4 | R3 | R2 | R1 | R0 |
|----------------------|-----|-----|----|----|----|----|----|----|
| RPC 5 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 1 |
| Data 0 for Command 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 |
| Data 1 for Command 1 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 |

AVAILABLE DAUGHTER CARDS

| PART NUMBER | FUNCTION |
|-------------|---------------------------------------------------------------|
| 7I29 | Dual 20A 165V HBridge |
| 7I30 | Quad 3A 36V HBridge |
| 7I31 | Debug LED card |
| 7I32 | Dual stepper driver (microstepping) |
| 7I33,7I33T | Quad analog servo interface |
| 7I34 | 8 TX + 8 RX pair RS-422 interface |
| 7I34-R | 16 RX pair RS-422 interface |
| 7I37,7I37T | 8 output 16 input isolated I/O |
| 7I39 | Dual 3 phase H-Bridge |
| 7I40 | Dual H-Bridge |
| 7I42 | I/O protector |
| 7I44 | 8 Channel RS-422 to RJ45 breakout |
| 7I46 | 6 channel SPI breakout |
| 7I47 | 12 channel encoder oriented RS-422 interface |
| 7I47S | 12 channel encoder interface with isolated spindle analog out |
| 7I48 | 6 channel analog servo interface |
| 7I49 | 6 channel resolver interface |
| 7I50 | SPI I/O expander |
| 7I64 | 24 input, 24 output isolated I/O |
| 7I65 | Octal16 bit A-D analog servo interface |
| 7I66-8 | 16 input 8 output isolated I/O |
| 7I66-24 | 24 output isolated I/O |

REFERENCE INFORMATION

SPECIFICATIONS

| | MIN | MAX | NOTES |
|--------------------------------|-------|-------|--------------------------------------------------------|
| SUPPLY VOLTAGE | 4.5V | 5.25V | |
| 3.3V CURRENT TO P2,P3,P4,P5 | ---- | 800mA | Typically limited to ~200 mA in USB powered case. |
| 5V CURRENT TO P3,P4 | ---- | 2A | Typically limited to ~150 mA in USB powered case. |
| 1.2V CORE POWER CURRENT | ---- | 1A | 1A = ~300 mA of 5V draw. Depends on FPGA configuration |
| MAXIMUM I/O I SINK OR I SOURCE | ---- | 24mA | |
| MAXIMUM I/O INPUT VOLTAGE | -.5V | 5.5V | 5V Tolerant mode. I/O 0..47, EPP I/O |
| MAXIMUM I/O INPUT VOLTAGE | -.5V | 4V | 3.3V mode. I/O 0..47 |
| TEMPERATURE -C VERSION | 0°C | 70°C | |
| TEMPERATURE -I VERSION | -40°C | 85°C | |